

V 1.0

Revised 4/30/18

# A-100 Analog Pressure Sensor

Reads Pressure (PSIG)

Range 100 PSIG (689.47 kPa)

Resolution 1mv (.025 psi /0.17 kPa)

Accuracy <= 0.1 PSI (0.689 kPa)


Response Time < 1ms

Data protocol Analog voltage


Data format **0.5 VDC – 4.5 VDC** 

Operating voltage 5 VDC

Durability IP67







### Absolute max ratings

VCC

Output current

Operating temperature

Proof pressure

Burst pressure

5.5 VDC 0.45 mA -40°C - 105°C 300 PSI (2,068 kPa) 900 PSI (6,205 kPa)


### **Power consumption**

5V **6 mA** 




### Operating principle

Internally the pressure sensor uses a piezoresistive semiconducting element. The semiconducting element (a silicon wafer) changes its resistance in proportion to pressure. As the pressure increases the atomic spacing of the silicon atoms decreases, this intern lowers the resistance of the silicon wafer.



Atmospheric pressure  $1M\Omega$ 



10 PSI (68.947 kPa) 500KΩ

An on-board microcontroller monitors the resistance and temperature of the semiconducting element. By combining these two parameters, the microcontroller computes the pressure and convert it into an analog voltage.

### Analog Output = 0.5 – 4.5 VDC

# Pressure 0 PSI (atmosphere) 20 psi 40 psi 60 psi 80 psi 100 psi

VOITS
0.5
1.3
2.1
2.9
3.7
4.5

### Voltage to PSI equation

 $PSI = 25 \times (Volts) - 12.5$ 


#### Voltage to kPa equation


 $kPa = 172.37 \times (Volts) - 86.185$ 

When the sensor is not under any pressure it may read a slight negative pressure. It is common to see negative readings from **-0.1** to **-0.14** This is due to floating point error when the sensor is not under pressure and should be ignored.



# **Typical applications**





## Submerge



DO NOT submerge

